


# TYPICAL LOAD-OUT APPLICATION



Typical load-out Multicor measures material extracted from a silo by rotary feeder and screw feeder.



MULTICOR

LOAD-OUT APPLICATION

For more information, please call the AccuRate Sales Department at 1-800-558-0184

CORLOAD(12/97)